

## 田植同時散布機の日安表



本表は目安表です。圃場条件等により変わりますので、散布テストを行い、ダイヤルの微調整を行って下さい。

イノベーター II / まくべえ II (丸山製作所)

型式: MGT-800A/MGT-800B

条数	株間 (cm)	株数 /坪	横送り回数							
			16	18	20	22	24	26	28	30
4条	30	37	3.00	3.50	3.75	4.00	4.25	4.75	5.00	5.50
	28	40	2.75	2.75	3.50	3.75	4.25	4.50	4.75	5.00
	26	42	2.50	2.50	3.25	3.50	4.00	4.25	4.50	4.75
	25	45	2.50	2.50	3.25	3.50	3.75	4.00	4.25	4.50
	22	50	2.25	2.25	2.75	3.00	3.25	3.75	3.75	4.00
	18	60	1.75	1.75	2.25	2.50	2.75	3.00	3.25	3.50
	16	70	1.50	1.50	2.00	2.25	2.50	2.75	2.75	3.00
	14	80	1.50	1.50	1.75	2.00	2.25	2.25	2.50	2.75
	12	90	1.00	1.00	1.50	1.75	1.75	2.00	2.25	2.25
	5条	30	37	3.75	4.25	4.50	4.75	5.25	5.50	5.75
28		40	3.50	4.00	4.25	4.50	5.00	5.25	5.50	5.75
26		42	3.25	3.75	4.00	4.25	4.75	5.00	5.25	5.50
25		45	3.25	3.50	4.00	4.25	4.50	4.75	5.00	5.25
22		50	2.75	3.00	3.50	3.75	4.00	4.25	4.50	4.75
18		60	2.25	2.50	2.75	3.00	3.50	3.75	4.00	4.25
16		70	2.00	2.25	2.50	2.75	3.00	3.25	3.50	3.75
14		80	1.75	2.00	2.25	2.50	2.75	2.75	3.00	3.25
12		90	1.50	1.75	2.00	2.25	2.25	2.50	2.75	2.75
6条		30	37	4.25	4.75	5.25	5.50	6.00	6.25	6.50
	28	40	4.25	4.50	5.00	5.25	5.75	6.00	6.25	6.50
	26	42	4.00	4.25	4.75	5.00	5.25	5.75	6.00	6.25
	25	45	3.75	4.25	4.50	4.75	5.25	5.50	5.75	6.25
	22	50	3.25	3.75	4.00	4.50	4.75	5.00	5.25	5.50
	18	60	2.75	3.00	3.75	3.75	4.00	4.25	4.50	4.75
	16	70	2.50	2.75	3.00	3.25	3.50	4.00	4.25	4.25
	14	80	2.25	2.50	2.75	3.00	3.25	3.50	3.75	4.00
	12	90	1.75	2.25	2.25	2.50	2.75	3.00	3.25	3.50
	7条	30	37	5.00	5.50	5.75	6.25	6.50	7.00	7.25
28		40	4.75	5.00	5.50	6.00	6.25	6.75	7.00	7.25
26		42	4.50	4.75	5.25	5.75	6.00	6.25	6.75	7.00
25		45	4.25	4.75	5.00	5.50	5.75	6.25	6.50	6.75
22		50	3.75	4.25	4.50	5.00	5.25	5.75	6.00	6.25
18		60	3.25	3.50	4.00	4.25	4.50	4.75	5.00	5.25
16		70	2.75	3.25	3.50	3.75	4.25	4.50	4.75	5.00
14		80	2.50	2.75	3.00	3.50	3.75	4.00	4.25	4.50
12		90	2.25	2.50	2.75	3.00	3.25	3.50	3.75	4.00
8条		30	37	5.50	6.00	6.50	6.75	7.25	7.50	8.00
	28	40	5.25	5.75	6.00	6.50	6.75	7.25	7.75	8.00
	26	42	5.00	5.25	5.75	6.25	6.75	7.00	7.25	7.50
	25	45	4.75	5.25	5.50	6.00	6.50	6.75	7.00	7.25
	22	50	4.25	4.75	5.00	5.50	5.75	6.25	6.50	6.75
	18	60	3.50	4.00	4.25	4.75	5.00	5.25	5.75	6.00
	16	70	3.25	3.50	4.00	4.25	4.50	5.00	5.25	5.50
	14	80	2.75	3.25	3.50	3.75	4.25	4.50	4.75	5.00
	12	90	2.50	2.75	2.75	3.25	3.50	4.00	4.25	4.25
	10条	30	37	6.50	7.00	7.50	7.75	8.50	8.75	9.25
28		40	6.25	6.50	7.00	7.50	8.00	8.50	8.75	9.25
26		42	5.75	6.25	6.75	7.25	7.50	8.00	8.50	8.75
25		45	5.50	6.00	6.50	7.00	7.25	7.75	8.25	8.50
22		50	5.00	5.50	6.00	6.50	6.75	7.25	7.50	8.00
18		60	4.25	4.75	5.25	5.50	6.00	6.25	6.50	7.00
16		70	4.00	4.25	4.75	5.00	5.50	5.75	6.25	6.50
14		80	3.50	4.00	4.25	4.50	5.00	5.25	5.50	5.75
12		90	3	3.25	3.75	4	4.25	4.75	5	5.25



本表は目安表です。圃場条件等により変わりますので、散布テストを行い、ダイヤルの微調整を行って下さい。

こまきちゃん(クボタ) CS-10

株間(cm)	条数と横送り回数(回)											
	4条			5条			6条			8条		
	16	20	26	16	20	26	16	20	26	16	20	26
12.0				1.8	2.4	3.2	2.2	2.9	3.9	3.1	4.0	5.3
13.0	1.5	2.0	2.7									
14.0	1.7	2.2	2.9	2.2	2.8	3.8	2.7	3.4	4.6	3.7	4.7	6.3
16.0	2.0	2.5	3.4	2.5	3.3	4.4	3.1	4.0	5.3	4.3	5.5	7.2
18.0	2.2	2.9	3.9	2.9	3.7	5.0	3.6	4.5	6.0	4.9	6.2	8.2
21.0	2.7	3.4	4.6	3.4	4.4	5.8	4.2	5.4	7.1	5.7	7.3	9.6
24.0	3.1	4.0	5.3	4.0	5.1	6.7	4.9	6.2	8.2	6.6	8.4	11.0

CS-20

株間(cm)	条数と横送り回数(回)								
	5条			6条			8条		
	16	20	26	16	20	26	16	20	26
14.0	2.0	2.5	3.0	2.3	3.0	3.8	3.0	3.8	5.0
16.0	2.3	2.8	3.5	2.8	3.3	4.3	3.5	4.5	5.5
18.0	2.5	3.0	4.0	3.0	3.8	4.8	4.0	5.0	6.5
21.0	3.0	3.5	4.8	3.5	4.3	5.5	4.5	5.8	7.5
24.0	3.3	4.0	5.3	4.0	5.0	6.5	5.0	6.3	8.0
30.0	4.0	5.0	6.8	5.0	6.3	8.0	6.5	8.3	10.5

PSR(ヤンマー)

条数	植付株数(/ 坪=3.3m <sup>2</sup> )					
	40	50	60	70	80	90
4条	1.8	1.3	1.0	0.9	0.8	0.7
5条	2.5	1.8	1.4	1.1	1.0	0.9
6条	3.8	2.4	1.8	1.5	1.4	1.0
8条	4.6	3.5	2.7	2.2	1.8	1.6

GS-1

株間(cm)	26cm	22cm	18cm	16cm	14cm
4条	6.5	5.0	5.5	5.0	4.5
5条	7.5	6.5	6.0	5.5	5.0
6条	8.0	7.0	6.5	6.0	5.5
7条	7.5	6.5	6.0	5.5	5.0
8条	8.0	7.0	6.5	6.0	5.5
10条	9.5	8.0	7.5	6.5	6.0